

#### 1341VDP



#### 配置文件







### 

DIN EN IEC 60900 (VDE 0682-201):2019-04; EN IEC 60900:2018

### 


- 材料:不□□
- 根据DIN EN IEC 60900 □□□□

### 

- 双[]-双色[[]提供[]外安全

### 重要事[]!

● 如果第二□□露出来,□立即更□您的VDE工具





<sup>\*</sup> Images of products are symbolic. All dimensions are in mm, and weight in grams. All listed dimensions may vary in tolerance.

## Frequently asked questions

# Are certified insulated tools made through a different procedure than non-certified insulated tools?

The tools are made according to the same procedure.

Are insulated (VDE) tools considered as personal protective equipment (PPE)? According to EU regulations, VDE tools are not considered as PPE.

### Are the VDE tools only being sampled in series production?

The high voltage test (at 10kV) is performed fully on each tool. Other tests are performed in accordance with the EN60900 standard.