

# 3/8"气∏棘∏扳手

1531



### 配置文件













#### 

- 每分∏250∏的空∏]速
- 最大扭力54 Nm
- 最大气[]: 6.2 Bar
- 空气消耗量71升/分□
- 1/4"ППП
- 最大螺栓尺寸M6

#### 

- 小型□□工具
- 高品[]生[]
- 易用气□开关
- 旋□方向的快速便捷□整
- 防止空气[]入工具的[][]


#### 用途:

- 汽[]行[]
- 航空□

- 重工[]
- 大型建筑机械
- 造船□

## 重要事[]!

■ 建□使用Unior气□套筒



		L	A	В	Nm	•
615318	3/8"	165	37	41	54	520

st Images of products are symbolic. All dimensions are in mm, and weight in grams. All listed dimensions may vary in tolerance.

# 用途 (pictures)



# Photo (pictures)



### Accessories












1/4"气]]]]]器和]滑器



3/8"气□□□□□器和□滑器



1/2"气□□□□□器和□滑器



## Safety tips



- The pressure in the tool during the operation has to be at least 6.2 bar for the tool to work properly.
- Regularly clean and dry the air filters and inlet air supply.
- Always use clean and dry air with the correct mixture of oil, for maximum tool life.
- Check the joints and ensure that the tubes and other equipment are not damaged before use.
- All tools should be gently oiled prior to being stored.
- Always store pneumatic tools in dry



• Always disconnect tools not in use from the air supply. places away from water.

- Always use original spare parts.
- Repairs can be performed only by authorised staff people authorised by Unior d.d.