

Tornavida takımı CR

607B5CR





Profiles



Product features

Set includes:

- 3x flat screwdriver CR (article 605CR) dim. 0.4x2.5x75, 0.8x4.0x100, 1.2x6.5x150
- 2x crosstip (PH) screwdriver CR (article 615CR) dim. PH 1x80, PH 2x100

Product name	SKU	Article	Dimensions	Quantity
Tornavida takımı CR	617021	607B5CR	-	5
Düz uçlu tornavida CR		605CR	0.4 x 2.5x75, 0.8 x 4.0x100, 1.2 x 6.5x150	3
Yıldız (PH) tornavida CR		615CR	PH 1x80, PH 2x100	2

* Ürünlerin resimleri semboliktir. Bütün boyutlar mm ve ağırlık gram cinsindedir.

Safety tips



- Use a screw holding screwdriver to get screws started in awkward, hard-to-reach areas.
- Use a stubby screwdriver in close quarters where a conventional screwdriver cannot be used.
- A rounded tip should be redressed with a file; make sure edges are straight.
- Screwdrivers used in the shop are best stored in a rack. This way, the proper selection of the right screwdriver can be quickly made.
- Keep the screwdriver handle clean; a greasy handle is apt to cause accidents.
- A screwdriver should never be used as pry bar. If it is overstressed in this manner, the blade might break and send a particle of steel into the operator's arm or even towards his eyes.



- Don't use pliers on the handle of a screwdriver to get extra turning power. A wrench should only be used on the square shank or bolster of a screwdriver that is especially designed for that purpose.
- Don't expose a screwdriver blade to excessive heat as it may reduce the hardness of the blade.
- Don't use a screwdriver with a split or broken handle.
- Don't use a regular screwdriver to check a storage battery or to determine if an electrical circuit is live.

Safety (pictures)

