

Piston ring compressor

2205



Profiles






Product features

use to install pistons on most passenger cars.

- high quality construction with sprung steel wraps
- with safety adjusting screws
- available in a wide range of sizes
- This tool is used to install pistons and piston rings into engine cylinders. Different sizes are available.

How to use the tool:

• Insert the piston and any piston rings into the tool, position the tool at the opening and use it to insert/push the piston and any piston rings into the cylinder.



	Н	D"	D	
619726	80	2 1/4"- 5"	57 - 125	291
619727	80	3 1/2" - 7"	90 - 175	320

^{*} Images of products are symbolic. All dimensions are in mm, and weight in grams. All listed dimensions may vary in tolerance.

Usage (pictures)







