

# Wkrętak krzyżakowy (PZ) TBI

625TBI



## Profile






## Standardy







ISO 8764

## Cechy produktu

- grot: stal chromo-wanadowa, twarda premium, całkowicie utwardzana i odpuszczana
- grot chromowany, czerniona końcówka
- rękojeść: ergonomiczny kształt
- trójkomponentowy materiał
- otwór do zawieszania
- wykonany zgodnie z ISO 8764-1,2




		C	L	D	
611741	PZ 0	60	145	3	34
611742	PZ 1	80	180	4.5	60

					
611743	PZ 2	100	210	6	93
611744	PZ 3	150	270	8	156

\* Przedstawiony wygląd produktu jest orientacyjny. Wszystkie wymiary są w mm, podana waga w gramach

## Użycie (Obrazy)



## Wskazówki bezpieczeństwa




- Use a screw holding screwdriver to get screws started in awkward, hard-to-reach areas.
- Use a stubby screwdriver in close quarters where a conventional screwdriver cannot be used.
- A rounded tip should be redressed with a file; make sure edges are straight.
- Screwdrivers used in the shop are best stored in a rack. This way, the proper selection of the right screwdriver can be quickly made.
- Keep the screwdriver handle clean; a greasy handle is apt to cause accidents.
- A screwdriver should never be used as pry bar. If it is overstressed in this manner, the blade might break and send a particle of steel into the operator's arm or even towards his eyes.



- Don't use pliers on the handle of a screwdriver to get extra turning power. A wrench should only be used on the square shank or bolster of a screwdriver that is especially designed for that purpose.
- Don't expose a screwdriver blade to excessive heat as it may reduce the hardness of the blade.
- Don't use a screwdriver with a split or broken handle.
- Don't use a regular screwdriver to check a storage battery or to determine if an electrical circuit is live.

## Bezpieczeństwo (Obrazy)



## Często zadawane pytania

### **Czy możesz uderzać we wkrętak?**

Nie, nie powinno się uderzać we wkrętak.

### **Jak czyścimy wielokomponentowy uchwyt?**

Środkami czyszczącymi przeznaczonymi do materiału PP/TPE.

### **Czy wkrętak z końcówką PH można stosować do śrub krzyżakowych PZ?**

Jego użycie nie jest zalecane, ponieważ może to spowodować uszkodzenie śruby.