

# Set de surubelnite TBI in suport SOS

## 964ECO9



### **Profile**




# Caracteristicile produsului

- Tool tray dimension: 498 x 135 x 30 mm
- Compatible with drawers of Economic line

#### Set includes:

- 4x TBI flat screwdriver (article 605TBI) dim. 0.5x3.0x80, 0.8x4.0x100, 1.0x5.5x125, 1.2x6.5x150
- 3x TBI crosstip (PH) screwdriver (article 615TBI) dim. PH 0x60, PH 1x80, PH 2x100
- 1x TBI double-crosstip (PZ) screwdriver (article 625TBI) dim.PZ 2x100



Denumirea Produsului	SKU	Articol	Dimensiuni	Cantitate
Set de surubelnite TBI in suport SOS	621292	964ECO9	-	8
Surubelnite plate TBI		605TBI	0.5 x 3.0x80, 0.8 x 4.0x100, 1.0 x 5.5x125, 1.2 x 6.5x150	4
Surubelnite TBI-(PH)		615TBI	PH 0x60, PH 1x80, PH 2x100	3
Surubelnite TBI-(PZ)		625TBI	PZ 2x100	1
Modul SOS pentru 964ECO9		vl964ECO9	498x135x30	1

<sup>\*</sup> Imaginea produsului este simbolica. Toate dimensiunile sunt exprimate în mm, greutatea în grame.

# Safety tips



- Use a screw holding screwdriver to get screws started in awkward, hard-to-reach areas
- Use a stubby screwdriver in close quarters where a conventional screwdriver cannot be used
- A rounded tip should be redressed with a file; make sure edges are straight.
- Screwdrivers used in the shop are best stored in a rack. This way, the proper selection of the right screwdriver can be quickly made.
- Keep the screwdriver handle clean; a greasy handle is apt to cause accidents.
- A screwdriver should never be used as pry bar. If it is overstressed in this manner, the blade might break and send a particle of steel into the operator's arm or even towards his eyes.



- Don't use pliers on the handle of a screwdriver to get extra turning power. A wrench should only be used on the square shank or bolster of a screwdriver that is especially designed for that purpose.
- Don't expose a screwdriver blade to excessive heat as it may reduce the hardness of the blade.
- Don't use a screwdriver with a split or broken handle.
- Don't use a regular screwdriver to check a storage battery or to determine if an electrical circuit is live.