

IRONGATOR engineer's vice

721/6




Profiles



Product features

- housing from grey iron casting
- drop forged jaws from tool carbon steel, hardened and tempered
- lacquered housing, jaws anticorrosive oiled, other parts zinc plated
- spindle protected against damage
- uniPRO slides ensure precise running of moving parts
- engineer's vice can be combined with swivel base



| | В | LŦ | L | D | H1 | a | b | Н | L1 | B1 | |
|--------|-----|-----|-----|---------|-----|----|----|-----|------|-----|-------|
| 621564 | 80 | 100 | 215 | 11 - 35 | 46 | 42 | 28 | 113 | 70.4 | 48 | 3500 |
| 621481 | 125 | 160 | 336 | 17 - 62 | 73 | 66 | 44 | 176 | 110 | 75 | 14400 |
| 621567 | 150 | 190 | 400 | 20 - 66 | 88 | 80 | 53 | 211 | 132 | 90 | 24200 |
| 621570 | 200 | 220 | 461 | 24 - 80 | 103 | 93 | 62 | 265 | 154 | 105 | 37800 |

^{*} Images of products are symbolic. All dimensions are in mm, and weight in grams. All listed dimensions may vary in tolerance.

Usage (pictures)





Accessories



Swivel base for 721/6 and 721Q/6



Spare aluminium jaws for 721/6 and 721Q/6

Spare parts



Spare jaw for 721/6 and 721Q/6



Spare aluminium jaws for 721/6 and 721Q/6

Safety tips





- Avoid clamping with heavy pressure on the corner of the vice jaws as it may break off a corner of a jaw.
- Don't use the jaws of a vice as an anvil.
- Never use an extension handle for extra clamping pressure.

- Replace a bent handle as soon as possible.
- Use bolts in all of the holes in the base of the vice.
- Use lock washers under the nuts.
- When work is held in a vice for sawing, saw as close to the jaws as possible to prevent vibrations. Be careful not to cut into the jaws.
- When clamping extra long work, support the far end of work rather than putting extra pressure on the vice.
- Regularly lightly oil all moving parts.
- If the threaded part of the vice is exposed, keep it free of chips and dirt.
- Discard any vice that exhibits the slightest hairline fracture.
- Always use a vice large enough to hold the work without strain.

- Never pound on the handle to tighten beyond hand pressure.
- Never try to repair a vice by welding or brazing.
- Don't try to bend a heavy rod in a light vice.