

# Stojan s pevnou platňou a čelistmi s nastavitelnou maticou

1693BS-US




Profiles



---



## Product features

- Stojan je navrhnutý pre servisy a každodenné použitie
- Pevná platňa je ergonomicky navrhnutá. Nosnosť: 30kg dovoľuje opravovať aj ťažšie zjazdové bicykle.
- Vhodné pre rúrky s priemerom min. Ø24 mm a max. Ø40 mm.
- Váha stojan je 36kg
- Vymeniteľné gumové chrániče čelustí, art. 1693.11



						
625013	985	1570	726	572	1700	38800

\* Obrázky sú symbolické. Všetky rozmery sú v mm, hmotnosť je v g. Všetky udané rozmery sa môžu líšiť v rámci tolerancie.


## Usage (pictures)




Adjust bike stand height? To adjust the bike stand height, release the lever (C) and adjust the top tube (D).



Adjust jaw angle and clamp bike safely? To adjust the bike stand jaw angle, release lever (F) and adjust/rotate (E).



Adjust opened jaw (G) to the seatpost or bike tube. Turn handle (H) until jaw firmly grabs the tube.



To adjust the jaw opening, turn the long screw (Z) with hand in needed direction as shown on picture.



Release bike safely from stand? To release, firmly hold bike frame. Flip handle (I) to quickly release tube from the jaw.



To mount the stand without fixed plate to the floor or ceiling, use appropriate screw anchors and screws (P) according to the floor/ceiling material, as shown on picture. Screws and screw anchors are not included.